

the future is safer with altro

PVCu wall cladding systems, ceiling systems and doorsets

recommended cleaning methods

Altro Whiterock[™] hygienic PVCu wall cladding, Altro Fortis[™] PVCu wall protection Altro PVCu doorset systems, Altro Whiterock[™] hygienic PVCu ceiling systems

Manual - weekly	
Wash with water or diluted soap / detergent solutions. Follow the manufacturer's dilution instructions.	Use a soft cloth only. Do not use abrasive cleaners, pads or wire wool.
Sterilisation and pressure cleaning	
 Sterilisation solutions (supplied by others) may be used following the manufacturer's instructions. Pressure cleaning with hot water lance may be carried out with the pressure nozzle a minimum of 600mm (approx 2 feet) from the wall surface. 	NB Observe maximum temperature of 60°C on all Altro PVCu products.
Heavy or stubborn stains	
 Clean heavily soiled areas with AltroClean[™] 44 cleaner or equivalent alkaline cleaner. Remove stubborn stains with Altro Whiterock Cleaner A859*. 	* NB Not to be used on Altro Whiterock Chameleon [™] or Altro Digiclad [™]
Dusty environments	
To reduce static charge after cleaning, apply Antistatic Solution A809 to all surfaces when dry.	

Failure to maintain Altro products in accordance with recommended procedure can affect performance. Further information is available from Altro Walls.

Please ensure you have the Health and Safety data sheet for any cleaner you intend to use. In the event of any queries, our Technical Services Department will be pleased to advise you.

Tips for successful maintenance of Altro PVCu walling, ceiling and doorsets

- Develop a regular cleaning programme suited to the usage and traffic of the area – heavy traffic or highly visible areas, or locations with rigorous hygiene requirements, need to be cleaned more often than areas which are seldom used, or where appearance is less important. A weekly cleaning programme is the minimum recommended.
- Use recommended cleaning chemicals use only recommended cleaning liquids, their equivalents or sterilising solutions in the correct concentration. Do not mix cleaning chemicals together, and always follow the manufacturer's instructions.
- 3. Remove scuff marks and heavy soiling regularly marks and soiling should be removed more often than the maintenance programme, e.g. daily. Never use abrasive pads or cleaners.
- 4. **Hot water lances can cause damage** use with care and never closer than 600mm or above maximum temperature recommendations.

High quality cleaning chemicals ensure efficient maintenance and represent only a small proportion of maintenance costs. A list of recommended suppliers can be found at www.altro.com, alternatively contact Altro for more information.

For further information or technical advice tel: +44 (0) 1462 707604 fax: +44 (0) 1462 707515 email: enquiries@altro.com or explore www.altro.com